


xxx = Ø Laufrad



Messwerte/Values/Valeurs: ±10%